


Ecoline - Diagram



23	MGBS-604-D01	Ignition	1	
22	MGBG-705A-A06	Main burner bracket	1	
21	MGBS-604A.B10	Main burner grasper (1.500)	1	
20	MGBG-604A.C10	Main burner tube 1	1	
19	MGBG-604A.C20	Semi-rapid burner tube 2	1	
18	MGBG-705A-A07	Auxiliary burner bracket	1	
17	MGBS-604.B30	Auxiliary burner grasper (1.500)	1	
16	MGBG-604A.C40	Auxiliary burner tube 1	1	
15	MGBG-705A.C60	Valve grasper	4	
14	MGBG-705A-A12	Main burner pan bracket	1	
13	MGBG-705A-A14	Semi-rapid pan bracket	3	
12	MGBG-705A-A15	Waterproof collar	4	
11	MGBG-705A-A04	Auxiliary water collector	1	
10	MGBG-705A-A01	Main water collector	1	
9	MGBG-705A-A03	Semi-rapid water collector	2	
8	MGBS-604-A06	Knob	4	
7	MGBG-604A-A01	Glass panel	1	
6	MGBS-604.C50	Intake gourpstre	1	
5	MGBG-604A.C30	Semi-rapid burner tube 3	1	
4	MGBS-604.B20	Semi-rapid burner grasper (1.700)	2	
3	MGBG-705A-A08	Semi-rapid burner bracket	2	
2	MGBS-604.A10	Installation bracket	4	
1	MGBG-705A-A19	Gas hob body	1	
Serial No.	Drawing number	Name	Number	Remarks